



For safety, this circuit must be plugged into a properly rated 120V outlet, GFI is recommended.

Chassis Ground (optional) is wired to 120VAC Power-In ground (green wire) for safety if you build your controller in a metal chassis.

Depending on your heater wattage, you may need to mount the heater SSR on a heat sink.  
The fan / heater outlets are one duplex outlet with the metal tabs on the sides removed.

<a href="http://www.kegkits.com">www.kegkits.com</a>		
MYPIN PID TA4-SSR 120V Greenhouse Controller		
Tom Hargrave	Rev 1.0	Page #1
	9/2/2013	