



For safety, this circuit must be plugged into a properly rated 120V outlet, GFI is recommended.
 Kitchens built since the early 1970s have two 20 Amp circuits, one run down each side of the kitchen.
 For commonly available heating elements, you'll need:
 1500 Watts = 12.5A, 1650 Watts = 13.75A, 2000 Watt = 17A.
 The power cord green wire must be bonded (firmly connected) to the metal outside of the heating element. This connection can be to the element itself or to the outside of the pot if the element is mounted in the pot.

www.kegkits.com		
120V Water Heater Element Wiring		
Tom Hargrave	Rev 1.0	Page #1
	4/28/2013	